



Mounting Suggestions

Harley-Davidson® 2006-201 Wide Tire Softail

(Will not fit on Softail Fatboy)

2006-201 Softail Crossbones

2006-201 Softail Custom

2006-201 Softail Night Tr i

Cyclone Solo Seat and Frame Mounting Plate

Installation Hardware Included:

- | | |
|--|---|
| (1) nose bracket #B30126 | (2) black rubber washers |
| (1) ¼-20 x 1 ½" long hex head bolt | (1) black plastic washer |
| (1) ¼-20 x ½" long Phillips truss head screw | (5) ¼ flat washers |
| (1) ¾" thick plastic spacer | (2) ¼-20 x 1 ½" long Phillips truss head screws |
| (2) ¼-20 flange nuts | (1) ¼-20 threaded stud |
| (2) ¼-20 x ¾" long Phillips truss head screw | (1) chrome washer |
| (2) rubber bumpers | (1) ¼-20 chrome acorn nut |

Attach Mustang Cyclone Solo seat to Frame Mounting Plate

1. Attach nose bracket #B30126 to bottom of frame mounting plate. Insert the ¼-20 x ½" long Phillips truss head screw from the top side, through the nose bracket, and secure with the ¼-20 flange nut.
2. Align three threaded inserts in bottom of solo seat with three holes in frame mounting plate.
3. At nose end, insert the ¼-20 x 1 ½" long hex head bolt with washer up through the nose bracket and frame mounting plate, through the ¾" thick plastic spacer and into threaded insert in nose of seat.
4. At back end of seat, insert the two ¼-20 x ¾" long Phillips truss head screws with washers up through the frame mounting plate, through the two flat black rubber washers and into the two threaded inserts in the bottom of the seat. Tighten all three fasteners.
5. If the solo seat will be used in the rearmost mounting position, two 5/16 holes must be drilled through the frame mounting plate at the indicated points. The two rear fasteners will be the ¼-20 x 1 ½" long Phillips truss head screws with washers and the two 5/8" thick rubber bumpers.

Attaching solo, steps 1-5



Install Frame Mounting Plate with solo seat onto motorcycle:

1. Remove stock seat(s). On Crossbones model, the stock HD frame cover must be permanently removed.
2. Locate the threaded hole at the top of the electrical box on the rear fender. Install the ¼-20 threaded stud with the plastic washer and flange nut as shown in the picture. Screw the stud in until there is exactly ¾" of thread remaining above the nut. Tighten nut.



3. Install the completed solo seat and frame mounting plate assembly onto the bike using the nose tab at the front end and aligning the rear hole with the stud installed in step 2 above.
4. Secure frame mounting plate with chrome washer and acorn nut.



**Enjoy the comfort of your
new Mustang seat!**



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 860-582-9633, Monday through Friday 9:00 - 5:30 Eastern or send an email to questions@mustangseats.com or visit our website at www.mustangseats.com For care and maintenance of our seats, please go to our website under "Support".

Ref: Cyclone Solo Seat part #'s 76615, 76616, 76617, 76618, 76621
Frame mounting plate: 76626