

Part Number: HD-XR12-F

Description: Front Saddle

Fitment: 2009-2010 Harley Davidson XR 1200

Revision: 1



Tools Required	Parts List
7/16" Open or Combination Wrench	1 #A01086 Front Locking Pin 1 (SP00214) Flat Washer 1 1/4" x 20 x 1.25" Hex head bolt

NOTE: We highly recommend using a removable strength thread lock product such as Loctite® on the bolts when installing your mounting bracket.

1. Start by removing the stock front seat from your motorcycle. Refer to your owner's manual if necessary.
2. Remove the front bolt and washer, using a 7/16" open or combination wrench (*Figure 1*). Discard bolt and washer.
3. Install the front locking pin where you removed the stock bolt and washer and secure with the supplied hex head bolt and flat washer, using a 7/16" open wrench (*Figure 2*). Use Loctite®.
4. Corbin's front saddle installs easily. Simply slide the saddle onto the bike rear first engaging the bracket, then lower the front of the saddle onto the front latch pin and push down on the saddle until you hear it click (*Figure 3*).
5. To remove the saddle, insert the key into the lock system, turn the key clockwise and pull it up from the front. If the key seems a bit stiff to turn, push down on the seat over the locking system, to assist the seat as the rubber grommets are new and need time to break in.



FIG 1



FIG 2



FIG 3

Questions? Give us a holler...
800-223-4332
tech@corbin.com