



INSTALLATION AND USE INSTRUCTIONS

TOOLS NEEDED: VARIES WITH BIKE MODEL

TIME TO INSTALL: 15-30 MINUTES

DIFFICULTY: EASY

INSTALLATION

- 1: REMOVE SEAT AND FACTORY CONSOLE PER H-D SERVICE MANUAL PROCEDURE. RETAIN HARDWARE FOR USE IN INSTALLATION.
- 2: REMOVE BATTERY COVER PER SERVICE MANUAL PROCEDURE.
- 3: USING 10MM WRENCH, LOOSEN AND REMOVE NEGATIVE (-) AND POSITIVE (+) BATTERY TERMINAL BOLTS.
- 4: INSPECT DASHLINK WIRING. RED POSITIVE (+) AND BLACK NEGATIVE (-) LEADS WILL ROUTE TO BATTERY. AUDIO JACK WILL ROUTE FORWARD (IN MOST CASES) TO FRAME NECK, OR TO RADIO LOCATION.
- 5: PLACE DASHLINK ON FUEL TANK MAKING SURE TO ROUTE WIRES AS DESCRIBED (OR FOR AUDIO, WHERE IT BEST APPLIES FOR YOUR APPLICATION). ROUTE ALL FACTORY LINES UNDER DASHLINK SO THEY ARE CONCEALED AND NOT PINCHED IN ANY WAY.
- 6: SECURE DASHLINK WITH HARDWARE REMOVED EARLIER, OR IN SPECIFIC INSTANCES WITH THOSE SUPPLIED. DO NOT OVER-TIGHTEN AS THIS MAY DAMAGE HOUSING.
- 7: INSTALL FUEL CAP.
- 8: CONNECT POWER LEADS TO BATTERY
- 9: CONNECT AUDIO JACK TO INPUT ON HEAD UNIT (ON FACE OF HARMON KARDON, AUX INPUT)

*Hell's Foundry, Inc - 7011 Grand River Rd, Brighton, MI 48114
Ph: 866.999.HELL (4355) Fax: 810.229.4372*



10: DOCK iPhone or iPod touch AND VERIFY DEVICE IS CHARGING.

11: TURN IGNITION TO ACCESSORY TO VERIFY AUDIO (MAKE SURE SOURCE IS ON AUX AND THE iDevice IS ON "PLAY")

12: TURN IGNITION TO "OFF"

13: INSTALL BATTERY COVER

14: INSTALL SEAT AND STRAP IF APPLICABLE

USE

1: **DOCKING:** INSERT THE iPhone or iPod touch FROM THE FORWARD OPENING AND SLIDE TOWARDS THE SEAT UNTIL IT CLICKS ON THE CONNECTOR. NEVER FORCE, IT SHOULD DOCK WITH LITTLE EFFORT.

2: **UN-DOCKING:** USING YOUR THUMB, PRESS LIGHTLY DOWN ON THE DEVICE AND PUSH FORWARD TO RELEASE FROM CONNECTOR. SLIDE FORWARD UNTIL FREE. WHEN FREE FROM CONNECTOR, SLIDE FORWARD AND LIFT.

3: AUDIO IS PROVIDED VIA THE CONNECTOR AT THE BASE OF THE PHONE, NOT FROM THE HEADPHONE JACK ON TOP.

4: **VOLUME ADJUSTMENT** IS THROUGH HAND CONTROLS WHICH CONTROL THE HEAD-UNIT. NO PROVISION IS MADE TO "SKIP" OR "PAUSE" MUSIC VIA THE HAND CONTROLS.

5: **CHARGING:** DASHLINK WILL ONLY CHARGE WHEN DEVICE IS DOCKED. NO CURRENT WILL BE PRESENT WHEN NO DEVICE IS DOCKED. CHARGING CAN BE VERIFIED BY THE BATTERY ICON DISPLAYING THE CHARGE SYMBOL.

CARE AND CLEANING

1: ALWAYS USE THE SUPPLIED SPLASH GUARD WHEN iDevice IS NOT DOCKED.

2: ELECTRICAL PARTS CLEANER AND COMPRESSED AIR "KEYBOARD CLEANER" FROM CANS CAN BE USED.

3: BRUSHES SHOULD NOT BE USED.

TIPS

1: TURN THE "SHAKE TO SHUFFLE" FEATURE OFF ON THE IPHONE OR IPOD TOUCH TO PREVENT TRACK "SKIPPING" WHILE RIDING. TO DO SO:

SETTINGS | IPOD | SHAKE TO SHUFFLE (OFF)

2: TURN THE EQ SETTING TO THE DESIRED SOUND LEVELS:

SETTINGS | IPOD | EQ (SELECT)



SOME EXPERIMENTATION MAY BE NEEDED TO SUIT YOUR PREFERENCE.

3: VOLUME CONTROL WILL ONLY WORK VIA RADIO CONTROLS. DASHLINK SUPPLIES LINE LEVEL OUTPUT.

ACCESSORIES

1: **SPLASH GUARD:** INSERT PROVIDED FORM FITTED SPLASH GUARD AS IF DOCKING A DEVICE. YOU SHOULD FEEL A CLICK AND LOCK. REMOVE IN THE SAME METHOD. ALWAYS USE SPLASH GUARD WHEN WASHING BIKE OR WHEN IT'S RAINING.



2: **SPACER:** PROVIDED FOR USE WITH IPOD TOUCH OR IPHONE 4 TO ELEVATE DEVICE TO ALIGN WITH DASHLINK CONNECTOR. DEVICE SHOULD DOCK WITHOUT FORCING. SIMPLY INSERT SPACER LIKE AN IDEVICE UNTIL IT LOCKS INTO PLACE UNDER THE CHARGE CONNECTOR.



3: **CASES:** SOME DEVICE CASES WORK WELL WITH DASHLINK, FOR EXAMPLE THE "INCIPIO SOFT SHELL" AND THE "GRIFFIN ÉLAN FORM" CASES FOR IPHONE 4 ALLOW PROPER CONNECTION AND ALIGNMENT.



WARNINGS

1: **YOUR iPhone and iPod touch ARE NOT WATERPROOF.** Do NOT DOCK OR LEAVE DOCKED IN A WET ENVIRONMENT. IF THERE IS WATER OR LIQUID PRESENT ON THE CONNECTOR, IT MUST BE DRIED PRIOR TO USE.

2: DO NOT REFUEL VEHICLE WHILE DEVICE IS DOCKED IN DASHLINK. IGNITION SHOULD BE TURNED TO "OFF" WHILE REFUELING.

3: DO NOT DOCK A DEVICE IN DASHLINK WHILE THE FUEL CAP IS OPEN OR MISSING.

4: DO NOT ATTEMPT TO MODIFY THE CURRENT FUNCTION OF YOUR DEVICE WHILE IN MOTION. MAKE ADJUSTMENTS ONLY WHEN STOPPED AND IT IS SAFE TO DO SO.

5: DO NOT TEXT MESSAGE WHILE VEHICLE IS IN MOTION.

6: YOUR IPHONE AND IPOD TOUCH HAVE BUILT-IN WARNINGS TO DETECT OVER-HEATING. PLEASE BE AWARE OF THEIR USE GUIDELINES.

NOTE: DISTRACTED DRIVING IS AGAINST THE LAW. TEXTING OR WORKING ON YOUR DEVICE WHILE MOVING MAY CAUSE INJURY TO YOURSELF OR OTHERS. ADJUST YOUR DEVICE ONLY WHEN STOPPED AND IT IS SAFE TO DO SO.

WARRANTY AND REGISTRATION

HELL'S FOUNDRY WARRANTS DASHLINK TO BE FREE OF DEFECTS FOR ONE YEAR FROM DATE OF PURCHASE. PLEASE REGISTER FOR YOUR WARRANTY AT: 866.999.4355

VISIT US ON FACEBOOK FOR OUR USER COMMUNITY AND APPLICATION RECOMMENDATIONS TO ENHANCE YOUR RIDING EXPERIENCE. WWW.FACEBOOK.COM/HELLSFOUNDRY



WWW.HELLSFOUNDRY.COM | WWW.FACEBOOK.COM/HELLSFOUNDRY



*Hell's Foundry, Inc - 7011 Grand River Rd, Brighton, MI 48114
Ph: 866.999.HELL (4355) Fax: 810.229.4372*